



Series 2 – Pushbutton Identification Table

NAME OF BUTTON	CODE	SHAPE	SIZE	PROFILE*
SS201	EA	Square	Small	High / Low
SS212	EC	Square	Small	High
SS204	EB	Square	Large	High / Low
SS214	ED	Square	Large	High
RS201	EE	Rectangle	Small	High / Low
RS203	EF	Rectangle	Large	High / Low
RS214	EG	Rectangle	Large	High
CS204	EL	Round	Large	Low
CS224	EM	Round	Large	Low
CS244	EN	Round	Large	Low
CS254	EP	Round	Large	Low

* The fitting of the spacer for Pushbuttons marked with “High / Low” determines the profile.